

How to Assemble?

Book Shelf • 2 shelves

Tool needed: Phillips screwdriver


- 1** Back rail × 2
- 2** Shelf panel × 2
- 3** Left side panel × 1
- 4** Right side panel × 1

Assembled size:

W 27.5 × D 9.4 × H 21.8 in

(698 × 238 × 554 mm)

Assemble on a soft, clean floor.



A

cam-lock insert ×14



B

cam bolt ×14



C



cam lock ×14




D

6 mm peg ×16



- 1** Shelf **2**: press insert **(A)** and 2 pegs **(D)** into the holes at the middle of the back edge, screw bolt **(B)** into **(A)**. Set back rail **1** on top, push cam **(C)** into the rail and turn it clockwise to lock. Make 2.



- 2** Lay left side panel **3** inside face up. Press inserts **A** into the 6 large holes and pegs **D** into the 6 small holes, then screw bolts **B** into the inserts by hand. Repeat on right side panel **4**.




- 3** Put cams **C** into the shelf and rail ends, arrow pointing to the edge. Slide both shelf units onto the bolts and pegs of **3**, then turn every cam clockwise to lock.





Cam **C** open side faces the board edge, so the bolt head can slide in. A half-turn clockwise locks it.

- 4** Put cams **C** into the other ends. Lower right side panel **4** onto the bolts and pegs, then turn the cams to lock.



- 5** Stand the shelf upright. Check every cam is tight.




clock-
wise

Safety Precautions!

- Place on a flat, level surface.
- Do not stand, sit or climb on the shelf.
- Spread heavy books evenly across each shelf.
- Avoid water contact; wipe spills right away.
- Re-tighten the cams if the shelf feels loose.

Taking it apart

- Lay the shelf on its side on a soft floor.
- Turn cams (C) anti-clockwise to release.
- Lift off side panel (4), then the shelf units.
- Keep all fittings (A)–(D) together.

Support: support@openwood.pk

**OPEN
WOOD**

www.openwood.pk